

Torberry Battery Leads – Very Important – Please read before using these leads

Torberry battery leads can be set up in 2 different combinations – it is crucial that the leads are set up correctly for your trolley.

Test the lead first by connecting them to your trolley before you connect the leads to a battery.

If it won't fit "red-to-red & black-to-black" then the leads need to be changed by following the following instructions:

Pull the black rubber shroud down the wires to reveal the red & black connectors (Fig. 1).

Separate the connectors by pulling the left one down and pushing the right one up (Fig. 2 & 3).

Swap the connectors over so the one which was on the left is now on the right.

Re-connect the connectors by reversing step 2.

Push the black shroud up and over the connectors by reversing step 1.

Finally, test on the trolley (before connecting the leads to a battery) to make sure that they now fit "red-to-red & black-to-black."

If you need help with this, please contact us on 028 9266 2738

